



CQT *Grain Scale*

Developed specifically for agricultural use, the CQT 1752GR grain scale calculates the potential yields, quality and development of grain crops. It offers a fast, portable and affordable weighing solution for checking grain quality as a percentage of the initial sample, after the grain has been sieved and graded. Its compact design and battery power operation enable use in the field when electricity is not available; an auto power-off function saves battery life. The integrated three-point ShockProtect[®] feature safeguards the load cell from overloads. For added security, a built-in slot is compatible with a Kensington-type lock and cable.



CQT Grain Scale

Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Programmable backlight can be set to “always on”, “always off” or “light only when weighing”
- Color-coded keys facilitate quick recognition of the most frequently used buttons
- Security slot for optional Kensington-type lock and cable to help prevent theft
- Large, type 304 stainless steel pan allows swift cleaning
- Rugged construction stands up to industrial use
- Three-point ShockProtect® feature prevents overload damage to internal components
- Auto power-off to save energy
- External calibration allows for verification and adjustment with weights
- Zero-tracking feature ensures display returns to zero reading
- Operates with AC adapter (included) or batteries (not included)

Applications

- Weighing

Model	CQT 1752GR
Capacity	1750g
Readability	0.05g
Repeatability (S.D.)	0.1g
Linearity (+/-)	0.1g
Pan Size	4.7" ø / 120mm ø
Weighing Units	g, kg/hL, lb/bu
Stabilization Time (sec)	2
Calibration	External calibration
Display	Backlit LCD with 0.7" / 18mm-high digits
Power Supply	12VAC 150mA adapter
Operating Temperature	0° to 40°C / 32° to 104°F
Housing	ABS
Draft Shield	Round 5.1" ø x 3.5" / 130mm ø x 90mm
Overall Dim.	6.7"x9.8"x3.1" / 171x250x80mm
Net Weight	1.76lb / 0.80kg

ACCESSORIES

308002042	Hard carrying case w/ lock
308232033	In-use wet cover
308232036	In-use wet cover (pack of 5)
308232037	In-use wet cover (pack of 10)
700100046	Kensington type lock and cable

Supplied by:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.